

Comfort

Comfort Utilities

Interior air filters

- Effective protection against pollutants from outside the car.
- Only for vehicles without air conditioning.
- To be placed into the airduct of the ventilation system.
- When installing the interior air filter filter, a plastic panel has to be removed from the inside of the airduct.
- Filter must be replaced once a year or every 10.000 km.
- Nissan 'Micron 2' system.

Description	Part Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	Start Of Sales
Interior air filter	KE278-60C00	9	F	95R	DE	19.20	05/95

Application	Specification	Countries	From	Until	Remarks	Fitting Time
N14		LHD	10/90	07/95		10-15
Y10		LHD	11/90	-		10-15
B13		LHD	10/90	10/94		10-15
W10		LHD	07/90	-		10-15

Description	Part Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	Start Of Sales
Interior air filter	KE278-70J00	9	F	95R	DE	19.20	05/92

Application	Specification	Countries	From	Until	Remarks	Fitting Time
P10E		LHD	06/90	06/96		10-15
A32		LHD	10/94	01/00		10-15

Description	Part Number	A-DC	E-DC	DC	Origin	E-RRP (Euro)	Start Of Sales
Interior air filter	KE278-19C00	9	F	95R	DE	19.20	10/92

Application	Specification	Countries	From	Until	Remarks	Fitting Time
C23M		LHD	07/92	-		10-15

